

Huntsman Centurion Walk-around Platform

Guidance and Care Instructions

Our walk-around platform is an awesome addition to your Centurion, but if you want to look after it and keep it awesome for years to come, we have a few guidelines for you to follow. We will provide a structural guarantee on the platform in line with our Five-Year Structural Hull Warranty that comes with all of our new boats, but only if you follow these guidelines. Any use of the platform outside of its intended purpose or going against these guidelines may void its warranty.

This document forms part of, and should be read in conjunction with, the terms of our Five-Year Structural Hull Warranty document. If your boat is outside of the five-year warranty period but your platform is newer and still within five years from date of installation, the platform will still be covered under warranty.

THERE ARE A FEW THINGS TO BE AWARE OF WITH THE PLATFORM:

- Your authorized Huntsman Boats dealer will help you to set the trim limit on your engine when your platform is fitted. The engine can be trimmed up and down for normal boating purposes within the platform space and will stop before hitting the platform if the trim has been set correctly. Any damage resulting from your own attempts to set the trim may void your warranty. Please speak to your dealer for help.
- If you need to access the back of the engine or propellor for any reason, there is a latch on the back of the platform that can be opened for more access. This latch should be securely closed when the boat is underway.
- There is a big hole in the middle of the platform where your engine goes. If the water is rough or you are backing up, occasionally water can spout up through this hole.
- Reversing into decent swells or at speed could make water wash over the back of the platform and in through the boat walk-through. The operator should be aware of the potential for this to happen and react accordingly.
- The stainless-steel rails and bait station can be removed. We recommend doing this on dry land before you go out.
- The platform is not intended for any form of towing, levering off, or tying down. If you are unsure of the correct towing or tying down points, please speak to your authorized Huntsman dealer.
- We have different variations of the platform depending on which engine you have on your boat. Different engines require different clearance in the centre of the platform. You should be aware of this if you wish to re-power or change your engine in future as a new engine may not fit that particular platform. If unsure, check with Huntsman Boats or your authorized Huntsman Boats dealer.

SAFETY:

- You shouldn't be on the platform while the engine is running or the boat is underway. The platform is intended to be used while the boat is stopped with the engine turned off.
- Max load 2 adult males, or about 200kg.
- We won't be responsible for anyone that hurts themselves in any way while using the platform. It's up to you to know your limits and wear suitable water flotation aids as required.

OTHER THINGS:

- Please don't try to remove or re-attach the platform yourself. We will only stand behind work that we (Huntsman Boats) have done, or work that has been done by someone approved by us.
- If you look after your U-dek, it will look after you. Please follow any guidance from Ultralon for care of their U-dek products. Any damage to the U-dek as a result of improper care or maintenance may not be covered.
- When you are filling your boat with petrol, be careful not to spill any fuel on the U-dek. The fuel might melt the adhesive and cause the U-dek to lift. If you do spill fuel, wash it off with water immediately.
- We reserve the right to update, change specifications or otherwise alter future iterations of the platform without assuming any obligation to modify any previously manufactured platforms.
- If you are unsure of anything relating to the platform or how it works, please contact Huntsman Boats or your authorized Huntsman Boats dealer.